

## Multipolar cable connection

EN

Connect the free end of the cable as described in the table.

MULTIPOLAR CABLE CONNECTION		
Cable number	Function MPX/MPXT	Manual reference MPX/MPXT
30	Video 1	Main camera output
31	Video 2	Infrared camera
26	L	L (Phase)
28	N	N (Neutral)
Earth	Earth (Green/Yellow)	Earth
1	485-A1	RS-485 line (1)
2	485-B1	RS-485 line (1)
3	485-A2	RS-485 line (2)
4	485-B2	RS-485 line (2)
5	W	Not used
6	GND	Ground connection
7	AL1	Alarm 1 (clean contact)
8	AL2	Alarm 2 (clean contact)
9	AL3	Alarm 3 (clean contact)
10	AL4	Alarm 4 (clean contact)
11	AL5	Alarm 5 (clean contact)
12	COM	A1-A2-A3-A4-A5 mass alarms
22	RL1	Relay 1 Terminal A
23	RL1	Relay 1 Terminal B
24	RL2	Relay 2 Terminal A
25	RL2	Relay 2 Terminal B

Tab. 1

## 複芯ケーブルの接続

JA

ケーブルの先端は、下表のとおり、接続します。

複芯ケーブルの接続		
ケーブル番号	MPX/MPXT側端子	用途 MPX/MPXT
30	Video 1	カメラ出力
31	Video 2	赤外線カメラ
26	L	L (位相)
28	N	N (中性)
アース線	アース線 (グリーン/イエロー)	アース線
1	485-A1 (+)	RS-485 ライン (1)
2	485-B1 (-)	RS-485 ライン (1)
3	485-A2 (+)	RS-485 ライン (2)
4	485-B2 (-)	RS-485 ライン (2)
5	W	使用しません
6	GND	Ground
7	AL1	アラーム 1 (クリーンコンタクト)
8	AL2	アラーム 2 (クリーンコンタクト)
9	AL3	アラーム 3 (クリーンコンタクト)
10	AL4	アラーム 4 (クリーンコンタクト)
11	AL5	アラーム 5 (クリーンコンタクト)
12	COM	A1-A2-A3-A4-A5 アラームのアース
22	RL1	リレー 1 端子 A
23	RL1	リレー 1 端子 B
24	RL2	リレー 2 端子 A
25	RL2	リレー 2 端子 B

表 1

